



How to Measure Your Wayne Dalton Garage Door

A	WIDTH
Exact	finished opening width — should equal the same size as the existing door
В	HEIGHT
Exact	finished opening height — should equal the same size as the existing door
C	SIDEROOM
	nce from the edge of the door opening to any wall or obstruction
D	HEADROOM
Dista	nce from the top of the finished existing door opening to the ceiling or underside of joists
Ε	ROOM DEPTH
Dista	nce from the finished door opening to the back point where hardware or the opener will extend

